

DRIVING ASSISTANT PLUS

Driving Assistant Plus is a camera- and radar-based equipment package which helps to automatically maintain your desired speed, lane, and distance to the vehicle in front of you, and brake in an emergency. Driving Assistant Plus also warns you about speed limits and allows you to change your speed seamlessly.


KEY FEATURES

DISTANCE CONTROL: Distance Control allows you to set your desired cruising speed and following distance from the vehicle ahead. When your BMW's cameras and radar sensors detect when the vehicle ahead slows down, your BMW automatically slows down and, if necessary, gently applies the brakes.

SPEED LIMIT ASSISTANT: Speed Limit Assistant detects when a speed limit changes and allows you to manually set the new speed limit for functions such as the Dynamic Cruise Control or Distance Control.

STEERING ASSISTANT: Steering Assistant supports the driver to maintain your BMW's position in the center of the lane. When necessary, the system provides a visual warning reminding the driver to keep hands on the wheel.





DRIVING ASSISTANT ACTIVATION

Pressing the **I/O** button on the steering wheel activates the **Driving Assistant Plus** features. With the **MODE** button, the driver can toggle between the **Keep Distance Mode** and the **Assisted Driving Mode**.


The **Keep Distance Mode** will use only **Distance Control** to maintain the vehicle's distance to the vehicle in front within the maximum set speed as determined by the driver.



The **Assisted Driving Mode** combines **Distance Control** and **Steering Assistant** which supports the driver by actively centering the vehicle in the lane, maintaining speed, and keeping distance to the vehicle ahead.

If activated in the **Settings** menu, **Keep Distance Mode** and **Assisted Driving Mode** speed limits can be quickly adjusted by pressing the **SET** button once it appears in the instrument cluster.

Disclaimer: Driver Assistance features are not a substitute for the driver's responsibility to operate the vehicle in a safe manner. Always pay attention to traffic, surroundings, and road conditions. Weather, traffic, road conditions and map data may affect performance. Please refer to your owner's manual or your BMW Center for more information.



FREQUENTLY ASKED QUESTIONS

1. What is Driving Assistant Plus?

Driving Assistant Plus is a camera- and radar-based equipment package which helps to automatically maintain your desired speed, lane, and distance to the vehicle in front of you, and brake in an emergency. Driving Assistant Plus also warns you about speed limits and allows you to change your speed seamlessly.

2. What are the requirements for Driving Assistant Plus?

Driving Assistant Plus is available on selected 2022 and newer vehicles. The availability of this feature depends on the hardware installed in your BMW. To confirm whether this is available on your vehicle, visit the ConnectedDrive store at <https://www.bmwusa.com/mybmwconnecteddrive>.

3. Is there a distracted driver safety feature built into Driving Assistant Plus?

Yes. The driver's attention is monitored by hands-on detection in the steering wheel and a camera that monitors the driver's focus. Use of the system does not remove the responsibility of the driver to assess visibility, traffic conditions and to intervene when needed. The driver should always use caution to reduce the risk of accidents.